


TJRC-剑眼6


机架组装说明书 Assembly manual




关注我们




机架组装(Rack assembly)




配件预组装(Pre assembly of accessories)




机架组装(Rack assembly)




配件预组装(Pre assembly of accessories)



机架组装(Rack assembly)




配件预组装(Pre assembly of accessories)




至此你已经完成整机的基本安装


At this point, you have completed the basic installation of the entire machine




机架组装(Rack assembly)



电池板安装(Battery plate installation)



机架组装(Rack assembly)



电池板拆卸(Battery plate removal)

