


Wireless earplugs User Manual




Model: T50

Support: voxzen-warranty@hotmail.com

Package List

Earplugs x 1
Type-C charging cable x 1
User manual x 1
Carrying bag x 1



- ① Digital LED Battery Status
- ② ③ + / - Buttons
- ④ MFB (Multifunction Button)
- ⑤ USB Port (on the right side)

Specifications


Working range	10 meters
Working time	40 hours (50% volume)
Charging time	about 2 hours
Battery	250mAh
Working temperature	-20 C - 50 C

Power ON/OFF

Press key	Operation	Action
MFB	Power On	Press and hold 3 second
MFB	Power Off	

Note: In pairing mode, if there is no connection for more than 3 minutes or the battery voltage is less than 3.1V, the headphones will automatically shut down.

Charger your earplugs



	Flashing red	Low power
	Steady red	Charging
	OFF	Fully charged

! Use the included USB cable to charge your earplugs and make sure it is fully charged before first use.

Pairing Instructions

- Press and hold the MFB button 3S, Indicator will flashing red and blue fast.
- Open the Bluetooth on your device and select "T50" start to pairing.



* When turned on, the earplugs will automatically connect to the last connected device if available. If not, it will enter pairing mode.

* Having connection problems? Remove "T50" from your device's Bluetooth history, ensure it's less than 3 feet away then try pairing again.

MFB (Multifunction Button) Instructions

Playing Music		
Press key	Operation	Action
MFB	Play / Pause music	Single press
+	Volume +	Single press
-	Volume -	Single press
+	Next Song	Press and hold
-	Previous Song	Press and hold

Voice assistant		
Press key	Operation	Action
MFB	Activate Voice Assistant	Press and hold 1S

Calling		
Press key	Operation	Action
MFB	Answer Call	Single press
	End Call	Single press
	Reject Call	Press and hold 1 second (when A call coming)

Sound Notifications

Functions	Voice
Turn on	Power on
Turn off	Power off
Bluetooth pairing	Pairing
Connected	Connected
Disconnected	Disconnected
Low battery	Please charging
Battery 70-100%	Battery high
Battery 30-70%	Battery medium
Battery 10-30%	Battery low

Indicators

Power on	Blue light flashes 1 second
Power off	Red light flashes 3 seconds
Pairing	Red and Blue light flashes alternately
Charging	Red light
Fully charged	Light off

Troubleshooting

1. The phone cannot find the earplugs:

Possible reasons:

- (1) The earplugs are not turned on and under standby mode;
- (2) Earphones program error;
- (3) Phone program error.

Solution:

- (1) Please turn off the earplugs and turn on again. And ensure that they are in the pairing state.
- (2) Please clear the pairing record of the earplugs.
- (3) Restarting the phone and clear all pairing data in the phone's Bluetooth.

2. No sound from earplugs:

Possible reasons:

- (1) Improper phone volume;
- (2) The earplugs are not properly connected to the phone;
- (3) The earplugs are out of operating range.

Solution:

- (1) Adjust the phone volume;
- (2) Reconnect the earplugs;
- (3) Keep the earplugs and phone within a range of 10m.

Precautions:

- (1) Do not perform any other actions while searching Bluetooth.
- (2) Please use earplugs near your phone to ensure signal stability.

3. The red indicator light does not light up during

charging Possible reasons:

The earplugs have not been used for a long time.

Solution:

Charge the earplugs for 30 minutes and the red indicator will light up.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.