



User Manual

What's Included



At a Glance



Using Your speaker

Turn ON/OFF:
Press and hold the power button for 2s

THE speaker will automatically turn off after 5 minutes if no device is connected.

Charger your speaker

Flashing red	Low power
Steady red	Charging
OFF	Fully charged



Use the included USB cable to charge your speaker and make sure it is fully charged before first use


Pair with your device

*Press and hold the power button 3s, Indicator will flashlight red and blue fast

*open the Bluetooth on your device and select "SP-002" start to pairing.

*When turned on, the speaker will automatically connect to the last connected device if available. If not, it will enter pairing mode

*Having connection problems? Remove "SP-002" from your device's Bluetooth history, ensure it's less than 3 feet away then try pairing again



Controls

Buttons	Operation	Action
○	Play/pause music	Single press
+	Volume +	Single press
-	Volume -	Single press
+	Next song	Long press 1 second
-	Previous song	Long press 1 second

Call

Buttons	Operation	Action
○	Answer call	Single press
○	End call	Single press
○	Reject call	Press and hold MFB for 2seconds (when a call coming)
○	Redial call	Double press

Voice assistant

○	Activate voice assistant	Press and hold 1second
○	Stop voice assistant	Press and hold 1second

Sound notifications

Function	Voice
Turn on	Power on
Turn off	Power off
Bluetooth paring	Paring
Connected	Connected
Disconnected	Disconnected
Battery High	Battery High
Battery Medium	Battery Medium (70%-100%)
Battery Low	Battery Low (30%-70%)
Low battery	Please charger (0%-30%)

Indicator

Power on	Blue light flashes 3 seconds
Power off	Blue and red light flashes 2 seconds
Paring	Red and blue light flashes alternately
Connected	Blue light flashes every 10 seconds
Charging	Red light
Fulled charged	Light off
Battery low	Red light flashes every 5 seconds

Specifications

Version	6.0
Input	5V=1A
Charging time	1.5hours
Worker range	15 meters
Working time	30 hours (50% volume)
Audio output	1.5W
Battery capacity	500mAh

FCC STATEMENT :
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help
RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



WARNING: DO NOT DISPOSE OF THE UNIT IN FIRE OR WATER. → NEVER ATTEMPT TO DISASSEMBLE AND REASSEMBLE. THESE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. RECYCLE WASTE FACILITIES DESIRED.
→ CHECK CHECK WITH YOUR LOCAL AUTHORITIES FOR RECYCLING ADVICE. KEEP YOUR DEVICE AND ALL ACCESSORIES OUT OF THE REACH OF CHILDREN AND ANIMALS. → SMALL PARTS CAN CAUSE SUFFOCATION OR INJURY. SMALL PARTS CAN CAUSE CHOKING OR SERIOUS INJURY TO SMALL CHILDREN. → AVOID EXPOSURE YOUR DEVICE TO VERY HOT OR VERY COLD TEMPERATURES (BELOW -10°C OR ABOVE 40°C, BELOW 0°C OR ABOVE 40°C). → EXTREME TEMPERATURES MAY CAUSE DISASSEMBLY OF THE DEVICE AND REDUCE THE CHARGING CAPACITY AND LIFETIME OF YOUR DEVICE. AVOID REDUCE THE CHARGING CAPACITY AND LIFE SPAN OF YOUR DEVICE. → DO NOT ALLOW YOUR DEVICE TO GET WET. LIQUIDS CAN CAUSE SERIOUS DAMAGE.
→ DO NOT HANDLE YOUR DEVICE WITH WET HANDS.