
WIRELESS SPEAKER



SP-005

User manual

Packing Details



Wireless Speaker



Charging Cable




3.5mm
Audio Cable



User Manual


Button Functions



1.Using Your Speaker


1.Turn ON/OFF

Press and hold the switch for 2s



⚠THE speaker will automatically turn off after 10 minutes if no device is connetcted.

2. Charger Your Speaker



☼	Flashing red	Low power
	Steady red	Charging
	OFF	Fully charged

⚠ Use the included USB cable to charge your speaker and make sure it is fully charged before first use.

3.Pair With Your Device

*Press and hold the power button 3s, Indicator will flashlight red and blue fast
*Open the Bluetooth on your device and select "**SP-005**"start to pairing.

☼

*When turned on, the speaker will automatically connect to the last connected device if available. If not, it will enter pairing mode

*Having connection problems? Remove "SP-005" from your device's Bluetooth history, ensure it's less than 3 feet away then try pairing again.

*TWS (True Wireless Stereo) Mode Two speakers can pair with each other for stereo sound. Both speakers can play the same audio (one as the left channel and the other as the right channel).
With one speaker connected to a smartphone, Press and hold ∞ into Tws mode

☼

The device must ensure less then 3 feet

TWS Mode

Press Key	Operation	Action
∞	Enter / Exit Tws Mode	Press and hold 2s

4.Controls

Music

Press Key	Operation	Action
⏯	Play/pause Music	Single Press
+	Volume +	Single Press
−	Volume -	Single Press
+	Next Song	Press and hold 2s
−	Previous Song	Press and hold 2s

Voice assistant

⏯	Activate Vioce Assistant	Press And Hold 1second
⏯	Stop Vioce Assistant	Press And Hold 1second

Call

Press Key	Operation	Action
⏯	Answer Call	Single Press
⏯	End Call	Single Press
⏯	Reject Call	Press And Hold 2second(When A Call Coming)
⏯	Redial Call	Double Press

Sound notifications

Function	Voice
Turn on	Power on
Turn off	Power off
Bluetooth pairing	Pairing
Connected	Connected
Disconnected	Disconnected
Battery high 70%-100%	Battery high
Battery Medium 30%-70%	Battery Medium
Battery low 10%-30%	Battery low
Low battery	Please charge
Tws Mode	Pairing
Tws Connected	Connected

Indicator

Power on	Blue light flashes 3 seconds
Power off	Blue light flashes 2 seconds
Pairing	Blue light flashes alternately
Connected	Blue light flashes every 10 seconds
Charging	Red light
Fully charged	Light off

Press the link button once to switch modes.

∞	X1	1. Mode 1: Flame
		2. Mode 2: Breathing
		3. Mode 3: Wander
		4. Mode 4: Rainbow
		5. Mode 5: Ocean Blue
		6. Turn off the lights

Specifications

Input	5V ⎓ 2A
Charging Time	4 hours
Working Range	15 meters
Working Time	30 hours (80% volume)
Audio Output	30 W (15W*2) (peak power)
Battery Capacity	9000mAh

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including
interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the
equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without